

## HEXAGON PAR P3

- 1、Voltage: AC220V/50Hz
- 2、Power consumption: 250W
- 4、Control proto(10channel
- 5、Control methods: DMX512, Master-Slave, Auto, Sound active
- 6、Dimming: 0~100% super linear dimming
- 7、Strobe: 25 t/s

8channel	FUNCTION	VALUE	description
1	Dimmer	0-255	From dark to bright
2	Strobe	0	blank
		1-255	from slow to fast (1HZ~25HZ)
3	R	0-255	From dark to bright
4	G	0-255	From dark to bright
5	B	0-255	From dark to bright
6	W	0-255	From dark to bright
7		0-20	From CH1 to CH6
		21-25	R
		26-30	G
		31-35	B
	36-40	W	
	40-45	R+G	
	46-50	R+B	
	51-55	G+B	
	Macro		

		56-60	R+ G+ B
		61-90	Built-in effect 1
		91-120	Built-in effect 2
		121-150	Built-in effect 3
		151-180	Built-in effect 4
		181-255	Built-in effect 5
8	Built-in effect speed	0-255	from slow to fast ( 1HZ~25HZ )
<b>10channel</b>	<b>FUNCTION</b>	<b>VALUE</b>	<b>description</b>
1	Macro	0-255	From dark to bright
2	Strobe	0	blank
		1-255	from slow to fast ( 1HZ~25HZ )
3	R	0-255	From dark to bright
4	G	0-255	From dark to bright
5	B	0-255	From dark to bright
6	W1	0-255	From dark to bright
7	W2	0-255	From dark to bright
8	W3	0-255	From dark to bright
9	Total dimming	0-20	channel 1--8
		21-25	R
		26-30	G
		31-35	B
		36-40	W
		40-45	R+G
		46-50	R+B
		51-55	G+B
		56-60	R+ G+ B
		61-90	Built-in effect 1
91-120	Built-in effect 2		

		121-150	Built-in effect 3
		151-180	Built-in effect 4
		181-255	Built-in effect 5
10	Built-in effect speed	0-255	from slow to fast (1HZ~25HZ)







序号	英文显示
1	ADDR
2	MANU
3	RUN
4	CHND
5	SOUD
6	LED
7	DISP
8	PSET
9	TILT
10	VER
11	FAET

说明
A001---A512 地址码
手动调节
运行模式选择 (DMX 自走 声控)
17CH、15CH 通道选择
ON, OFF 音控开关
ON, OFF 背景灯开关
YES, NO 反向显示
YES, NO 电机X 反向
YES, NO 电机Y反向
V101 软件版本号
YES, NO 恢复出厂设置